





Original Operating Manual:

Laser Light Barriers LB*-L50-LSR/LDI(-OP) / LB*-L50-EVA(-OP) LBN-L50-LSR/LDI-OP/LBD-L50-EVA-OP

· Range 50m.

LBD-L50-LSR/LDI-OP/LBD-L50-EVA-OP
IECEX BVS 14.0108X





Ex d [op is Ga] IIC T6 Gb

Housing M18 · Short response time

· Optimal alignment help by status indication trough the illuminated receiver lens

With optional emitter disable input
With pollution indication output
Series LBD:For use in Ex-Zones 1(0), 2(0), 21(20), 22(20)

• Series LBN: For use in Ex-Zones 2, 22

II 3G Ex nA op is IIB T4 Gc

| • Series LBN: For use in Ex-Zones 2, 22 | | | | I 3D Extc op is IIIA T135°C Dc IP6 | |
|---|--|--------------------------------------|---------------------------------------|--------------------------------------|--|
| Technical data Emitters Receivers | LBS-L50-LSR/LDI LBS-L50-EVA | LBN-L50-LSR LBN-L50-E | | LBD-L50-LSR/LDI-OP LBD-L50-EVA-OP | |
| Designation, emitter with disable input | | LBx-L50-S- | | | |
| Type of Ex protection Gas, in accordance with 2014/34/EU | none | II 3G Ex nA op is | | II 2(1)G Ex d [op is Ga] IIC T6 G | |
| Type of Ex protection Dust, in accordance with 2014/34/EU | none | II 3D Extcor | | II 2(1)D Ex tb [op is Da] IIIB | |
| Type of Exproteotion Buot, in accordance with 2014/04/20 | 110110 | T135°CDc | | T100°C Db IP67 | |
| For use in Ex Zones | Not for Ex zones | 2, 22 | IF 07 | (0), 1, 2, (20), 21, 22 | |
| Sensing range | NOTION LX ZONES | 50m | | (0), 1, 2, (20), 21, 22 | |
| | | | | | |
| Minimum detectable object size | <u> </u> | 10mm (avoid m | | 2 | |
| Light source | l | _aser, visible red, 6 | | 2 | |
| Maximum radiant power | | <=1m\ | | | |
| Maximum radiant intensity | NOT LIMITED | <=5mW/i | | <=5mW/mm ² | |
| Directional angle of the receiver | appr. 17°. (at a distance of 10m) | | | | |
| Response time | | 5ms | | | |
| Supply voltage | | 24 VDC + | -10% | | |
| Current consumption, emitter | | 40m/ | \ | | |
| Current consumption, receiver | | 50m/ | \ | | |
| Maximum power dissipation | F | Emitter = 1.1W / Receiver = 1.4W | | | |
| Output & Pollution indication output "VA" | | PNP, 100mA, short circuit protected | | | |
| Electrical input, only type LB*-L50- LDI (-OP) | Disable input, PNP compatible | | | | |
| | 000 4 T 4 4 6000 | Disable Iliput, FIN | | | |
| Maximum ambient working temperature Note 1 | 0°C < T _{amb} < +60°C | 2000 | 0°C < Tamb | < +50°C | |
| Storage temperature range | | -20°C + | | | |
| Relative humidity | | 15% 90%, nonce | ondensing | | |
| Pollution degree, according to EN 60664-1 | | 4 | | | |
| Utilization category, according to EN 60947-5-1/2 | | DC13 | | | |
| Housing | | M18, brass, nic | kel plated | | |
| Enclosure rating, in accordance with EN 60529 | IP 54 | | IP6 | 57 | |
| Vibration and shock resistance | Vibration: 30 | Og over 20Hz to 2k | Hz. Shock: 1 | 00g for 3ms | |
| Connection cable, shielded | Special PVC/PVC | Ĭ | Special P | VC/PVC | |
| | 2/3/4xAWG24/0.25mm²,L=5m | 2/3// | • | .25mm². L=10m | |
| DC/LDN LE0 ***/ OD) C000: Cooket M12 Lumbers | | RSF 5, 5 te | | .2011111 , L=10111 | |
| _BS/LBN-L50-***(-OP)-S099: Socket M12, Lumberg | RSF 5, 5 terminals | | | | |
| BS/LBN-L50-***(-OP)-S096: Cord set 10cm, M12, Lumberg | RSTS 5-298, 5 terminals | RSTS 5-298, 5 | terminals | | |
| Accessories Accessories, only LBN-L50-***-OP-S096/S099 | - 4 nuts M18 or optional 2 cla - 2x Safety lock device, mo | | | | |
| Accessories optional, only LBS/LBN-L50-***-S096/S099 | | ensor socket. raight type: RKTS 5 | 5-298/M or | | |
| | ut connector M12/5 terminals, Cor RSF 5, 5 terminals situng TPU, shielded, oil and solv situng TPU, shielded, oil and solv | d set Lumberg RST | S 5-298. | | |
| Additional "Tubus M18/90/8": Aperture tube, open by | | | | | |
| LED Indication | , | | | | |
| Function | | <u> </u> | _ | | |
| unction | Light beam interrupte | d | Light bo | am not interrupted | |
| | | u | • | · · | |
| | LED's shows red | | LED'S SNO | ws yellow or green | |
| Dutput | | -○ +24VDC | | ○ +24VDC | |
| Niring and and connection layout, see page 2 | 7 | | ţ (| | |
| | | - Output - OV | | Output OV | |
| Pollution indication output VA | PNP=OFF | | PNP | =ON, if LED=yellow | |
| • | | m interrupted / n | | , , , , , , , , , , , , , , , , , , | |
| Alignment and Controlling by LED Display | | | | al. | |
| (Trough the receiver lens and at the rearside of | | | oadly aligne | d | |
| the receiver) | LED green: Light bea | m free / v | well aligned | | |
| EX related markings CE1258 | _ | Manufact | urer with address | \$ | |
| TypesLBD: Ex | od [op is Ga] IIC T6 Gb, 3G Ex nA op is IIB T4 Gc, | Extb[opi | s Da] IIIB T100° cop is IIIA T135° | C Db IP67 | |

Types LBD:

Types LBD:

Types LBN:

Note 1: On temperatures less the +5°C, the cable must not be agitated

ATEX certification

IECEx certification

ATEX declaration by manufacturer

Tamb: 0°C < Tamb < +50°C Electric Date of production: Numerals 5 to 8 of the serial number (year/calendar week)

Page 1 of 2

No: BVS 10 ATEX E130 X DEKRA

IECEx BVS14.0108X in accordance with the ATEX directive 2014/34/EU

Electrical data according to the table "Technical data"

info@tippkemper-matrix.com

Operating Manual / EU - Declaration of Conformity:

Operating Manual:

Ex protection:

General prescriptions for all Ex devices:

It is necessary to take into consideration the valid international and national rules and regulations (EN 60079-14). The maximum input voltage Um=30VDC must not be exceeded. The local equipotential bonding have to be done. The protective earth (PE) terminal is solid connected with the housing. The cable have to be protected against damages. To connect cables inside hazardous locations only use certificated Ex housings. All cable terminals must be connected outside hazardous locations. Use only original manufactured fibre optics and additional optical lenses, other additional optical lenses are not allowed in hazardous locations.

Type LBD-L50-***-OP: Applicable in Ex zones 1, 2, 21, 22. The limited optical radiation can operate into hazardous locations 0 or 20 through a certificated viewing glass.

Type LBN-L50-***-OP: Only applicable in Ex zones 2, 22.
Type LBN-L50-***-OP-S096/S099: Only applicable in Ex zones 2, 22. Do

not separate the connector when the supply voltage is connected to the cable. When installing the sensor, the safety lock device must be fitted at the cable connector. The additional adhesive warning label must be fixed to the connector housing at the connection cable. Lumberg cordsets RKTS 5-298/xx (Straight type) or RKWTH 5-298/xx (Right angle type) are allowed ONLY. It is necessary to take into consideration the mounting prescription of the connector manufacturer. In dusty locations, the socket protection cap must be fitted, when the connection cable is not connected. General mounting prescriptions:

Do not exceed the maximum ratings. The electrical connections must be exactly as shown in the connection diagram. The cable shield must be connected short. The cable shield should be connected to the protection earth, large-surfaced. Connection cables must not be installed parallel to high voltage cables.

Function:

-Bx-L50-OP-IECEX

If the light beam is not interrupted the output switches to ON (+24V). If the light beam is interrupted the output switches OFF. The load must be connected between the output and 0V

Function, devices LB*-L50-EVA(-OP)-S179:

If the light beam is not interrupted the output switches to OFF. If the light beam is interrupted the output switches to ON (+24VDC). The load must be connected between the output and 0V. Pollution indication output "VA":

The VA output will be activated by polluted lenses or a bad alignment. If the lenses are polluted, the LED shows yellow and the VA output switches to ON (+24V). This function gives the possibility to recognize pollutions in a short time.

Arrangement of light barriers, only types LB*-L50-LDI(-OP):

If several light barriers are installed close to another, it is necessary to use light barriers with emitters with disable input. By using the disable input DI, each emitter can be controlled in a short reaction time. If only one emitter is activated in the same time, a mutual influence is precluded. = emitter enabled

DI= 0V or not connected DI=

High (24VDC) = emitter disabled

The Disable Input DI must be activated for >= 7ms. The DI input is PNP compatible.

Mechanical Mounting Prescriptions

Because Lasers have a very small aperture angle, mount the light barriers

free from vibrations and shocks. If it is practicable, protect the lenses from contamination

Alignment of the Light Barrier

The three color indication in the receiver optic allows an optimal alignment. The emitter laser beam must hit the receiver lens in an angle near

2. The receiver should be moved, until the LED (from the receiver) shows "green". Search the middle of the green range.

Maintenance:

No special maintenance is required. If the lenses becomes dirty, they should be cleaned with a non-aggressive solvents. Equipment must only be repaired by the manufacturer.

Safety Informations for Laser Installations of Class 2:

The instructions for planning and installation must be followed in accordance with EN 60825-1. Do not stare into Laser Beam

General safety instructions Series LBN-L50-***-OP-S096/S099: "WARNING - EXPLOSION HAZARD -WHEN IN HAZARDOUS LOCATIONS, TURN OFF POWER BEFORE REPLACING OR WIRING MODULES. DO NOT DISCONNECT EQUIPMENT UNLESS POWER HAS BEEN SWITCHED OFF OR THE AREA IS KNOWN TO BE NONHAZARDOUS". The mounting of the sensor in dusty locations without fixed cordset or protection cap results in a high ignition risk. The sensors must not be used for Accident-Prevention! In worst case the output can change to any state! When installing and operating with the sensor, it is necessary to take into consideration the relevant international and other national regulations: EN 60079-14, single directive 1999/92/EC. The sensors are conform to the following standards: IEC/EN 60079-0:2012 + A11:2013, IEC/EN 60079-1:2007, EN 60079-15:2010, IEC/EN 60079-28:2007, IEC/EN 60079-31:2010, EN 60529:2014, EN 60950-1:2006; EN 61000-4-2 to EN 61000-4-6, EN 61000-6-1/-2, EN 61000-6-4, ATEX directive: 2014/34/EU, Machine directive: 2006/42/EC, EMC directive: 2014/30/EU, RoHS directive: 2011/65/EU.

General Notes, disposal

We reserve the right to modify our equipment. Our equipment is designed such way, that it has the least possible adverse effect on the environment. It neither emit or contain any damaging or siliconized substances and use a minimum of energy and resources. No longer usable or irreparable units must be disposed of in accordance with local waste disposal regulations.

EU-Declaration of conformity:

IECEx certification, types ILD: Ex d [op is Ga] IIC T6 Gb, Ex tb [op is Da] IIIB T100°C Db IP67. Certification No. IECEx BVS 14.0108X.

ATEX certification, types LBD: II 2(1)G Ex d [op is Ga] IIC T6 Gb, II 2(1)D Ex tb [op is Da] IIIB T100°C Db IP67. Certification No. BVS 10 ATEX E 130 X, DEKRA EXAM GmbH, Zertifizierungsstelle, Carl-Beyling-Haus, Dinendahlstrasse 9, D-44809 Bochum, Kennnummer: 0158. ATEX certification, types LBN: II 3G Ex d op is IIB T4 Gc, II 3D Ex tc op is IIIA T135°C Dc IP67. ATEX declaration by manufacturer in accordance to the ATEX directive 2014/34/EU. IECEx/ATEX certification of quality type production of Ex devices in accordance to the ATEX directive 2014/34/EU, CE 1258, Eurofins. Certification No: SEV 21 ATEX 4580, QAR No. CH/SEV/ QAR21.0009/00. The conformity of the devices with the EC standards and directives and the EC-type examination certificate and the observation of the Quality Safety System ISO 9001:2015 with the ATEX module 'Production", declares:

Pablo Ledergerber, Matrix Elektronik AG

(Manufacturer) Kirchweg 24 CH-5420 Ehrendingen

Page 2 of 2