

Original operating manual:
Glass Fibre Optics
VA-**-4-I-1GD/VA-****-4-I-2GD/VAM-****-4-I**

 II 1 G IIC T4 Ga, II 1D IIIB T135°C Da
 or
 II 2 G IIB T4 Gb, II 2D IIIB T135°C Db

- Special steel protection sheath, for light barrier measurement method
- VA-****-4-I-1GD: For use in Ex Zones 0, 1, 2, 20, 21, 22
- VA-****-4-I-2GD: For use in Ex Zones 1, 2, 21, 22
- VAM-****-4-I: For use in Non-Hazardous Locations up to Ta=+200°C

| Technical data | Type | VA-****-4-I-1GD | VA-****-4-I-2GD | VAM-****-4-I |
|---|------|--|-----------------------|-----------------------|
| Standard length and designation | | ****=Length in mm, from 200mm to 7000mm (Overall length) | | |
| Ex Protection, Gas | | II 1G IIC T4 Ga | II 2G IIB T4 Gb | none |
| Ex Protection, Dust | | II 1D IIIB T135°C Da | II 2D IIIB T135°C Db | none |
| For use in Ex Zones | | 0, 1, 2, 20, 21, 22 | 1, 2, 21, 22 | -- |
| Requirement at connected sensors | | Ex op is Ga/Da | Ex op is Gb/Db | none |
| Maximum optical input power | | <=15mW | <=35mW | not limited |
| Maximum potential radiant intensity | | <=5mW/mm ² | <=5mW/mm ² | not limited |
| Active fibre optic diameter | | 4 mm | | |
| Active cross-sectional area | | 12.6mm ² | | |
| Transmission rate, average | | 50-70%, at 870nm | | |
| Optical aperture | | appr. 65°, at 870nm | | |
| Individual fibre diameter | | 50um | | |
| Minimum bending radius | | 50mm (Single bend) | | |
| Operating temperature range Tamb | | 0°C < Tamb < +120°C | | -20°C < Tamb < +200°C |
| Enclosure rating, according to EN 60529 | | IP 68 | | |
| Material, adaption probe tip | | Special steel, 1.4305 | | |
| Material, probe tip | | Special steel, 1.4305 | | |
| Material, protection sheath | | Special steel, 1.4301 | | |
| Accessories, included | | 2 x Shrink-down plastic tubing | -- | |
| Accessories, not included | | - Additional optics type OT-VA (Material: brass) | | |
| Options | | -- | | |

ATEX RELATED MARKINGS

CE 0158 Tamb= 0°C < Tamb < +120°C

Manufacturer with address

Type: VA-****-4-I-1GD

Date of production: Numerals 5 to 8 of the serial number (year / calendar week)

Type: VA-****-4-I-2GD




II 1G IIC T4 Ga, II 1D IIIB T135°C Da

EC-Certification No. BVS 10 ATEX E 130 X. DEKRA

II 2G IIB T4 Gb, II 2D IIIB T135°C Db

EC-Certification No. BVS 10 ATEX E 130 X. DEKRA

(X designation of the certification number: Fibre optics must only be applied with sensors with certificated limited optical power)

Dimensions:

Operating Manual / EC - Declaration of Conformity:
Ex mounting prescriptions
Type VA-**-4-I-1GD: For use in Ex zones 0, 1, 2, 20, 21, 22.**
Type VA-**-4-I-2GD: Only for use in Ex zones 1, 2, 21, 22.**
General regulations for all types:

The maximum rated optical input power must not be exceeded. The local equipotential bonding have to be done by grounding the fixed sensor. It is necessary to take into consideration the valid international and national rules and regulations (EN 60079-14). Other than original manufacturer, additional optical lenses are not allowed in hazardous locations. The fibre optics have to be installed in a manner to avoid tensile stress and frictional heat. If fibre optics and associated sensors are not mounted in the same hazardous location, the change over of the different areas must be realized in accordance with the valid regulations. With the additional shrink-down plastic tubings (only types VA-****-4-I-1GD) a required change over can be realized.

Function

The fibre optics series VA are designed for the construction of light barrier measurement method arrangements in hazardous locations and for high ambient temperatures. The fibre optics can be operated with certificated Matrix sensors, with an optical wave length from 500nm to 900nm. The fibre optics must not be buckled or laid with a small radius. Buckled or bad laid fibre optics results to a strong decrease of performance. Avoid performance decreasing and failures caused by wear, by a functional mounting of the fibre optics.

Maintenance

The fibre optics are maintenance-free. Protect the fibre optics against pollution. If they are contaminated, clean with alcohol. Do not use aggressive solvents. Equipment must only be repaired or serviced by the manufacturer.

Safety Informations

When installing and operating, it is necessary to take into consideration the relevant international and other national regulations. EN 60079-14, single directive 1999/92/EC.

Standards met:

- EN 13463-1:2009, EN 60079-28:2007

- ATEX directive: 94/9/EC

- Machine directive: 2006/42/EC

- RoHS directive: 2011/65/EU

General Notes, disposal

We reserve the right to modify our equipment. Our equipment is designed such way, that it has the least possible adverse effect on the environment. No longer usable or irreparable units must be disposed of in accordance with local waste disposal regulations.

EC-Declaration of Conformity

ATEX certification: Certification No. BVS 10 ATEX E 130 X, DEKRA EXAM GmbH, Zertifizierungsstelle, Carl-Beyling-Haus, Dinendahlstrasse 9, D-44809 Bochum, Kennnummer: 0158.

ATEX certification of quality type production of Ex devices at the directive 94/9/EC, CE 0158. Certification No: BVS 12 ATEX ZQS / E118. The conformity of the devices with the EC standards and directives and the EC-type examination certificate and the observation of the Quality Safety System ISO 9001:2008 with the ATEX module "Production", declares:


 Hans Bracher, Matrix Elektronik AG

Tippkemper - Matrix GmbH
 Meeger Str. 43 D-51491 Overath
 Tel.: +49 2206 9566-0 Fax - 19
 info@tippkemper-matrix.com

Matrix Elektronik AG (Manufacturer)
 Kirchweg 24 CH-5420 Ehrendingen
 Tel.: +41 56 20400-20 Fax -29
 info@matrix-elektronik.com